

STYLE# R21553

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

Carefully unpack all lamp parts from carton. We suggest a licensed electrician for all fixture installations.

- 1. Take the lamp carefully out of the Carton, and place on a flat surface.
- 2. Be sure power to the installation point is OFF.
- **3.**Pull the power supply wire out from the outlet box and mount the **Universal Bar** to the outlet box with Outlet Box Screws.
- 4. Assembly Fixture Body as following:
 - Step 1. Take the Leather Shade place on a flat surface. Then put Metal Ring on the top of Leather Shade.
 - Step 2. Place Part D onto Leather Shade. Take the bottom of Part B into Part C and secure with Screw#2. Tighten until snug.
 - Step 3. Take the top of Part B into Part A and secure with Screw#1. Tighten until snug.
 - Step 4. Fixture Body assembly is complete.
- 5. Adjust the length of wire needed for your installation, remove excessed wire. Determine the number of **Rods** to be assembled to the **Fixture Body** as needed for your hanging height. Pull the Supply Wire along with Ground Wire through the selected **Rods** and Swivel. Thread the **Rods** with connected **Nipple**. Hand tighten.
- **6**. Connect the wire as shown.
 - a. Connect the House Ground Wire to the Fixture Ground Wire, secure with wire nut.
 - b.Connect the House White (or Ribbed) Wire to the Fixture Supply Wire (White or Ribbed Side), secure with wire nut.
 - c.Connect the House Black (or Red) Wire to the Fixture Supply Wire (Black or Smooth Side), secure with wire nut.
 - d.Carefully stuff all of the connected wires into the Outlet Box.
- 7. Place the Canopy over the Mounting Screws and secure with Mounting Balls. Hand-tighten until snug.
- 8. Install the correct Edison Bulb(Not Included) into the Socket until snug.

Your installation is complete. Turn electrical power back on.

