

LED Floor Lamp

FL46660
INSTALLATION SHEET

START FROM HERE


- Prepare everything in a clear area
- Wear gloves at all times during this installation
- Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

Please Note:

- This Kuzco LED fixture comes with pre-wired LED module(s)
- Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- Touch Dimmer

- 1.** Remove fixture from its original package
- 2.** Apply appropriate amount of glue to threaded joint, wait two minutes for glue to activate, and then connect the rods (**2d**) together.
- 3.** Insert into base connector (**3f**) and use wrench provided (**3a**) to tighten lock nut (**3e**) in place and thread on cover (**3g**).
- 4.** Lock post in place with set screws (**4a**) using Allen Key (**4b**) provided.
- 5.** Gently slide lamp head (**3c**) onto magnetic connector (**3d**)
- 6.** Plug driver (**3h**) into outlet.
- 7.** Use hand to activate dimmer (**2a**). Touch and hold to dim, touch to turn on/off and select which light comes on.



KUZCO

19054 28th Avenue Surrey, BC Canada V3Z 6M3
T: 604 538 7162 TF: 1-855 85 KUZCO F: 604 538 7196
W: kuzcolighting.com
20191230