

# REVELATION




BY U. TERMOSE

## ASSEMBLY INSTRUCTIONS

STYLE# R21299

Carefully unpack all lamp parts from the carton.

1. Take the lamp carefully out of the **Carton**, and place it on a flat surface.
2. Be sure the power to the installation point is power off.
3. Thread the **Loop** onto the **Nipple #1** on the top of the **Lamp body**. Hand tighten until snug.
4. Fix the **Quick link** onto the **Loop**. Hand tighten until snug.
5. Thread **Nipple #2** through the center of **Washer #1** and **canopy**, then secure onto the **Canopy Chain Loop** with **Hex Nut #1**.
6. Thread **Washer #3** and **Washer #4** onto **Nipple #3**, then secure with **Hex Nut #4**.
7. Locate the **Coupling** and thread onto **Nipple #3** protruding into the **Outlet Box**. Thread **Coupling** onto pipe until tight.
8. Proceed to thread **Hex Nut #2** and **Washer #2** onto **Nipple #2** until **Nipple #2** seated against the bottom of the **Coupling**.
9. Connect the wires as shown : A. Connect the House Ground Wire to the Fixture Ground Wire.  
B. Connect the House White or Ribbed Wire to the Fixture Supply Wire (White or Ribbed Side).  
C. Connect the House Black/Red Wire to the Fixture Supply Wire (Black or Smooth Side).  
D. Wrap each connected wire with **Wire Connector** and carefully stuff all of the connected wires into the Outlet Box.
10. Pass the supply wires through the hole in the center of the **Loop** and wind it through the **Chain**. Then through the **Canopy** and **Nipple #2** on the cross bar.



R21299

PO BOX 53870325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24157

www.revelationbyuitermosel.com

**INSTALLATION INSTRUCTIONS:**

(FOR FIXTURES OVER 50 LBS.)

PLEASE USE THE INFORMATION OUTLINED IN THIS SHEET FOR THE CEILING INSTALLATION PART OF YOUR FIXTURE ASSEMBLY.

1. BEFORE INSTALLING FIXTURE, CAREFULLY UNPACK AND IDENTIFY ALL PARTS REFERRING TO ILLUSTRATION FIGURE 1.

BE SURE THE POWER TO THE INSTALLATION POINT IS OFF.

2. THE WEIGHT OF THIS FIXTURE WILL REQUIRE A MEANS OF SUPPORT INDEPENDENT OF THE OUTLET BOX. THIS FIXTURE MUST BE SUPPORTED BY THREADED NIPPLE. THE THREADED NIPPLE SHOULD BE POSITIONED SO THAT 3/4" PROTRUDES INTO THE OUTLET BOX CAVITY.

3. WITH THE NIPPLE PROPERLY SITUATED, LOCATE COUPLING AND PROCEED TO THREAD ON TO THE END OF THE NIPPLE PROTRUDING INTO THE OUTLET BOX. THREAD COUPLING ON TO NIPPLE UNTIL TIGHT.

**4. MAKING THE CONNECTIONS:**

PROCEED TO UNRAVEL THE FIXTURE SUPPLY AND GROUND WIRES. LOCATE THE FITURE CHAIN AND ATTACH ONE END TO THE FIXTURE LOOP WITH QUICK LINK AT THE TOP OF FIXTURE.

PROCEED TO PASS THE FIXTURE SUPPLY AND GROUND WIRES THROUGH THE CHAIN, ALTERNATING LINKS.

PROCEED THE PASS THE WIRES THROUGH THE FOLLOWING.

MOUNTING COMPONENTS IN THIS ORDER:

- 1) CANOPY LOCK RING
- 2) CEILING CANOPY
- 3) CANOPY CHAIN LOOP
- 4) SHAKE PROOF WASHER B AND LOCK NUT B
- 5) NIPPLE
- 6) LOCK NUT A AND SHAKE PROOF WASHER A.

PROCEED TO THE THREAD THE NIPPLE INTO THE BOTTOM CENTER OF THE COUNPLING UNTIL TIGHT. TIGHTEN THE LOWER SET SCREW.

PROCEED TO THREAD LOCK NUT A AND SHAKE PROOF WASHER A UP NIPPLE UNTIL SEATED AGAINST THE BOTTOM OF THE COUPLING.

PROCEED TO ATTACH THE FIXTURE GROUND WIRE TO HOUSE GROUND WIRE USING WIRE CONNECTORS, USING WIRE CONNECTORS CONNECT THE HOUSE WHITE WIRE TO THE FIXTURE SUPPLY WIRE, CONNECT THE HOUSE BLACK WIRE TO THE FIXTURE SUPPLY WIRE.

**5. WITH THE PROPER CONNECTIONS MADE**

PROCEED TO THREAD THE CANOPY CHAIN LOOP ONTO THE BOTTOM OF THE NIPPLE.

PROCEED TO ATTACH THE TOP QUICK LINK TO THE TOP OF FIXTURE CHAIN

PROCEED TO ATTACH THE QUICK LINK TO THE BOTTOM OF THE CANOPY CHAIN LOOP.


PROCEED TO THREAD LOCK NUT B AND SHAKE PROOF WASHER B DOWN ONTO THE

TOP OF THE CANOPY CHAIN LOOP

**6. PROCEED TO PUSH THE CEILING CANOPY UPWARD OVER THE OUTLET BOX.**

SECURE CANOPY AGAINST CEILING BY THREADING CANOPY LOCK RING

ONTO THE CANOPY LOOP. TIGHTEN UNTIL SNUG.



# UTTERMOST LIGHTING

## INSTALLATION INSTRUCTION FOR SAFETY CABLE INSTALLATION

### IN INSTRUCTION:

THIS FIXTURE IS PROVIDED WITH A SAFETY CABLE. THE SAFETY CABLE PROVIDES A BACK UP SYSTEM OF THE FIXTURE'S FRAME AND THE INSTALLATION HARDWARE. IT IS ESSENTIAL THAT THE SAFETY CABLE BE PROPERLY INSTALLED. THE CABLE MUST BE SECURED TO A STRUCTURAL MEMBER OF THE BUILDING, AND NOT TO THE OUTLET BOX. THE CABLE MUST BE TERMINATED WITH CLAMP'S SPECIFICALLY SIZED FOR THE CABLE. IF THE U-CLAMPS ARE USED, THEY MUST BE ORIENTATED AS PER THE DRAWING BELOW. IF THE CABLE HAS A PLASTIC COVERING, IT MUST BE REMOVED FROM THE AREA WHERE THE CLAMPS ARE MOUNTED. MAKE SURE ALL HARD WARE IS PROPERLY TIGHTENED AND THAT THE CABLE IS POSITIONED CLEAR OF ANY OBSTRUCTIONS.

### CORRECT APPLICATION

